

Homemade Moravian sausages

Cuisine: **Czech**
Food category: **Minced meat**




Author: [Vlastimil Jaša](#)


Company: [Retigo](#)





Program steps


1


 Hot air


 0 %

 Termination by time


 00:35 hh:mm


 70 °C


 100 %





2


 Hot air


 0 %

 Termination by time

 00:50 hh:mm

 75 °C

 50 %



Ingredients - number of portions - 20		
Name	Value	Unit
boneless front beef	2000	g
fatty pork	500	g
boneless pork shoulder	500	g
pork belly, minced	500	g
freshly ground black pepper, ground	10	g
ground red pepper	10	g
caraway seeds	10	g
garlic	45	g

Nutrition and allergens	
Allergens:	
Minerals: Ca, Co, Cr, Cu, F, Fe, I, K, Mg, Mn, Na, P, Se, Zn	
Vitamins: A, B, B6, C, E, K	
Nutritional value of one portion	Value
Energy	419 kJ
Carbohydrate	1.4 g
Fat	32.7 g
Protein	31.1 g
Water	0 g

Directions

We salt the meat, both beef and pork, and let it sit in the cold for about a day.

Then grind the beef front and pork cut (it should be very fat) finely and twice. The size of the disc for the meat grinder should be 2 mm, not larger.

Then add about half a liter of cold water to the minced meat and mix well (clean).

When the "Prát" is well mixed, add the spices and mix properly and let it sit.


We grind the shoulder and the belly in a grinder with a coarse disc, which we mix thoroughly with seasoned laundry, the mass must be homogeneous.

We then fill the mixture with a medium-caliber pork intestines sausage stuffer, which we leave in lukewarm salted water for a long enough time before that.


This is how we smoke stuffed sausages.

"Caution" the first step is drying, and then in the second step we insert the smoker into the chamber of the combi oven.

Recommended accessories



Vision Smoker



Stainless wire shelving